

Product Registration

When using your product for the first time, it is recommended that you immediately register it. This will give you access to some useful benefits, such as:

- Faster service from our trained representatives.
- Membership in the Acer community: receive promotions and participate in customer surveys.
- The latest news from Acer.

Hurry and register, as other advantages await you!

How to register

To register your Acer product, please visit **www.acer.com**. Select your country, click **Register a product** and follow the simple instructions.

After we receive your product registration, you will be sent a confirmation email with important data that you should keep in a safe place.

Obtaining Acer accessories

We are happy to inform you that Acer's warranty extension program and accessories are available online. Come and visit our online shop and find what you need at **store.acer.com**.

The Acer store is being progressively rolled out, and, unfortunately may not be available in some regions. Please check back regularly to see when it will be available in your country.

Model number: _____

Serial number: _____

Date of purchase: _____

Place of purchase: _____

Table of contents

Your Acer Chromebase tour	4
Front view	4
Base view	5
Rear view	6
Environment	7
 Getting started	 8
Plug in and set up your Acer Chromebase	8
Turn on your Acer Chromebase	8
Using the touchscreen	8
Select your language settings	9
Connect to a network	9
Sign in to your Google Account	9
 The Chrome OS Desktop	 11
Desktop overview	11
 Apps	 13
Managing apps	13
Google Drive	13
Gmail	15
Google Docs	15
YouTube	15
Playing video or audio files	16
Other Supported File Types	16
Chrome Web Store	16
 Chrome tips and tricks	 17
 Settings	 23
Changing the language settings	23
Changing the clock settings	24
Customizing appearance	24
Setting up a printer	25
Updating Chrome OS	25

Help	26
Online and offline help	26

Information for your safety and comfort 27

Safety instructions	27
Radio frequency interference	30
Medical devices	30
Vehicles	31
Potentially explosive environments	32
Emergency calls	32
Disposal instructions	32
Tips and information for comfortable use	33


Regulations and safety notices 36


FCC notice	36
LCD pixel statement	37
Federal Communications Commission Declaration of Conformity	38

Your Acer Chromebase tour


Now that you are done setting it up, let us show you around your new Acer Chromebase.





Front view




#	Icon	Item	Description
1		Webcam	Web camera for video communication. <i>A light next to the webcam indicates that the webcam is active.</i>
2		Stereo microphones	Internal microphones for sound recording.
3		Screen	Displays computer output. <i>Some models support touch input.</i>
4		Power key	Turns the computer on and off.
5		Speakers	Left and right speakers deliver stereo audio output.






Base view



#	Icon	Item	Description
1		USB ports	Connect to USB devices. <i>If a port is black it is USB 2.0 compatible, if it is blue it is also USB 3.0 compatible and supports fast charging.</i>
2		HDMI-out port	Supports high-definition digital video connections.
3		Ethernet (RJ-45) port	Connects to an Ethernet 10/100-based network.
4		DC-in jack	Connects to an AC adapter.

Rear view



#	Icon	Item	Description
1		USB port	Connects to USB devices. <i>If a port is black it is USB 2.0 compatible, if it is blue it is also USB 3.0 compatible.</i>
2		Headset/speaker jack	Connects to audio devices (e.g., speakers, headphones), or a headset with microphone.
3		SD™ card reader	Accepts Secure Digital (SD™) cards. Note: The card reader uses one card at a time.
4	 	Kensington lock slot	Connects to a Kensington-compatible computer security lock. Note: Wrap the computer security lock cable around an immovable object such as a table or handle of a locked drawer. Insert the lock into the notch and turn the key to secure the lock. Some keyless models are also available.
5		Shutdown / reset pinhole	Shuts down and resets the computer. <i>Insert a small, thin object (such as a paperclip).</i>



Note: Items 1, 2, and 3 are located behind a cover on the rear of your computer.


Environment

- Temperature:
 - Operating: 5 °C to 35 °C
 - Non-operating: -20 °C to 65 °C
 - Humidity (non-condensing):
 - Operating: 20% to 80%
 - Non-operating: 20% to 80%
-


Getting started

Plug in and set up your Acer Chromebase

Open the stand until it snaps in place. Then, tilt the display panel to an angle of between 15 and 75 degrees from an upright position.



Connect the DC-in jack to your Acer Chromebase and plug the AC adapter into an AC outlet.



Turn on your Acer Chromebase

On the Acer Chromebase, the power button is located in the lower-right corner beneath the screen. A "connect" screen will appear when the Acer Chromebase first boots up.

Using the touchscreen

Your Acer Chromebase uses a touchscreen for selecting items and entering information. Use your finger to tap the screen. You may use the following gestures:

Tap: Touch the screen once to open items and select items.

Drag: Hold your finger on the screen and drag across the screen to select text and images.

Tap and hold: Tap and hold an item to see a list of actions available for that item. From the pop-up menu that appears, tap the action you want to perform.

Scroll: To scroll up or down the screen, simply drag your finger up or down the screen in the direction that you want to scroll.

Select your language settings

Use the "Select your language" drop-down list to choose your default language setting. If there is more than one way to type in your language, you may be prompted to select a keyboard input method as well.

Connect to a network

Connect to a network using the built-in LAN jack at the rear of the computer or select a wireless network from the "Select a network" list to connect to the Internet. If wireless network access is protected, you will need an access password to connect to it.

Accept the Terms of Service

Once connected to a network, accept the Terms of Service. Your Acer Chromebase will then download any available system updates, so you automatically get the latest Chrome OS features.

Sign in to your Google Account

If you already have a Google Account, enter your username and password in the sign-in box that appears and click on the **Sign in** button.

<p>Sign in Google</p> <p>Email Acerguides@gmail.com</p> <p>Password *****</p> <p>Sign in</p>	<p>If you don't have a Google Account, you can Create a Google Account now.</p> <p>You may also skip sign in and Browse as Guest.</p>
---	---



Important: Sign in with your primary Google Account. This account will be set as the owner and is the only account that will be able to change certain Chrome settings.

Create a new Google Account

You can create a new Google Account if you don't already have one. Click **Create a Google Account** on the right to set up a new account. A Google Account gives you access to useful web services developed by Google, such as Gmail, Google Docs, and Google Calendar.


Browse as a guest

You can also use the Acer Chromebase without a Google Account by clicking **Browse as a Guest** on the left.

Set your account picture


This picture will represent your account on the main sign-in screen and status area. If you like, you can use the Acer Chromebase's built-in webcam to take a photo. If you don't want to take a photo at this time, you can choose an icon instead. You can always update your picture after you've signed in.

Also, your Acer Chromebase is integrated with your Google account profile. After signing in with your Google account you have the option of choosing your Google account profile picture.



The Chrome OS Desktop







Desktop overview











Window controls

Icon	Description	Icon	Description
	Close a tab		Open a new tab
	Minimize, maximize, or dock the window on the left or right		Close the window
	Back to the previous page		Go to the next page
	Reload the page		Search
	Bookmark		Chrome controls

Launcher

Icon	Description	Icon	Description
	Google Chrome		Gmail
	Google Search		YouTube
	Google Drive		Apps list

Status area and settings

Icon	Description	Icon	Description
	Chrome OS help		Shut down
	Lock screen		Settings
	Battery status		Volume control
	Bluetooth status		Wireless network connection



Note: Specifications vary. Some icons may not be applicable to your Acer Chromebase.

Apps

Managing apps

Installing apps in Chrome OS

See "**Installing new apps from the Chrome Web Store**" on page 16.

Removing apps from Chrome OS

1. Click the apps list button (⌵).
2. Right-click on the app you want to remove.
3. Select **Remove from Chrome**.

Customizing apps pinned to the launcher

1. Click the apps list button (⌵).
2. Right-click on the app you want to add to the launcher.
3. Select **Pin to Launcher**.

To reorder the apps in the launcher, just drag them around.

Google Drive

All files saved to your *Google Drive* are saved online and are accessible to other devices, such as your smartphone or tablet. Files saved to the *Downloads* folder are saved to your local drive and are only accessible to your Acer Chromebase.




.....


Note: You must be connected to the Internet to do the following Google Drive operations.

Sync files from Downloads to Google Drive


1. In the apps list, click on the **Files** icon.



2. If this your first time accessing your Google Drive, click on the *Google Drive* icon to enable access.
3. Once your Google Drive is enabled, select the files that you want to upload.




4. Drag-and-drop the files on to *Google Drive*.



Enable offline access to Google Drive files

You can access files stored on your Google Drive while offline, but first you must enable offline access:

1. In the Apps panel, click on the **Files** icon, then click on **Google Drive**.
2. Select the file (s) you want to access offline.
3. Right-click to bring up the context sensitive menu and click on **Available offline**. A check mark will appear to indicate the file is available offline.




Gmail

Composing an email

1. From the launcher, click on the **Gmail** icon.
2. Click **COMPOSE**.
3. Enter the recipient's email address, the subject, and the message.
4. When you are finished composing your message, click **Send**.

Google Docs

Creating a new document

1. From the launcher, click on the **Google Drive** icon (.
2. Click on **CREATE** and select the type of document you want to create.

YouTube

YouTube is a video-sharing website on which users can upload, share and view videos. You can access it by clicking the **YouTube** icon on the launcher.

Playing video or audio files

Your Acer Chromebase has a built-in media player to play audio and video files. To play a file, double-click on an audio or video file in your *Files* app.

Media type	Supported formats
Audio / Video	.3gp, .avi, .mov, .mp4, .m4v, .m4a, .mp3, .mkv, .ogv, .ogm, .ogg, .oga, .webm, .wav

Other Supported File Types

Your Acer Chromebase supports a number of other file formats.

File type	Supported formats
Microsoft Office files	.doc, .docx, .ppt, .pptx, .xls, .xlsx – (all read-only)
Images	.bmp, .gif, .jpg, .jpeg, .png, .webp
Compressed	.zip, .rar, .tar, .tar.gz (.tgz), .tar.bz2 (.tbz2)
Other	.txt, .pdf

Chrome Web Store

Installing new apps from the Chrome Web Store

1. Click the apps list button (⌵) and then click on **Chrome Web Store**.
2. You can then browse through the app categories in the left column or search for a specific type of app using the search box.
3. When you find an app that you would like to add, hover your mouse over it and then click on **ADD TO CHROME**.
4. A verification window will pop up, click on **Add** to download and install the app, or click on **Cancel**.
5. To open your new app, click the apps list button (⌵) and then click on the app.

Chrome tips and tricks

Your Acer Chromebase is a new type of computer that works somewhat differently than what you may be used to, so you might like to know how easy and useful things are when using it. Here are some tips and tricks.

How to create documents

1. Press the **Search** key on your keyboard.

Press



2. Click on **Google Docs**.

Click



That's it. You've just created a new document in less than one second. With your new document, you can add text, insert images, change the font, make it bold, underline it, italicize it – you get the gist. You can also click **Google Sheets** to create spreadsheets and **Google Slides** to create presentations.

Click




or



How to share documents with other users

1. Click the **Share** button in the upper right corner of your document.

Click



-
2. Add people by typing in their email address.
 3. After you click **Done**, they'll receive an email letting them know a document has been shared with them.

Click



To find your document later, press the **Share** key and click on the **Google Drive** icon – this opens Google Drive, which shows you a list of your files and folders. You can search for files by name at the top of the screen.

How to start a video chat

1. Press the **Search** key and click on the **Hangouts call** icon.

Press

Click



-
2. Type in the name or email address of a person.

3. Click the **Submit** button to start your Hangout.

Click

Submit

For all you Skype users out there, Google+ Hangouts are free video chats for up to ten people.

How to listen to music

Google Play Music

1. Press the **Search** key and click **Google Play Music**.

Press

Click



2. To discover or buy songs, use the search box at the top.
3. To play a song, just double-click on it.
4. All of the music you upload or buy will be saved under **My Music**.

For other streaming apps like Pandora, Spotify, Rdio, Deezer and more (availability varies by country):

1. Press the **Search** key and click on **Store** to go to the Chrome Web Store, then do a search for **Pandora** or other music apps.

Press

Click



2. When you find what you want, click the **Add to Chrome** button.

How to watch videos, TV, or movies

YouTube

1. Press the **Search** key, click **YouTube** and you're ready to roll.

Press

Click



Google Play Movies

1. Press the **Search** key and click **Google Play Movies**.

Press

Click



To find more entertainment apps like Netflix, Flixster, and more (availability varies by country):

1. Press the **Search** key and click **Store**.

Press

Click



-
2. Select **Entertainment** on the left side.
 3. Choose **TV & Movies**.

How to open Microsoft Word and Excel documents

1. Press the **Search** key and click **Files**.



2. Double-click on any **Microsoft Office** file stored in Google Drive or on an external hard drive or USB flash drive connected to your Acer Chromebase.

You can convert Microsoft Word and Excel files into Google Drive Documents and Spreadsheets and edit them. You can also export Google Drive documents and spreadsheets as Microsoft Office files.

How to use your Acer Chromebase when there's no internet

Gmail:

1. Press the **Search** key and click on **Store** to go to the Chrome Web Store, then search for **Gmail Offline** in the upper left corner search box, and add it.



2. The next time you find yourself offline, press the **Search** key.



3. Click **Gmail Offline** to open it, and use Gmail like you normally would. It'll update and send your emails the next time you log on to the internet.

Click



Google Docs, Sheets, and Slides:

1. When you open Google Drive while connected to the internet, it will automatically enable Offline Drive.
2. Once the process completes, the next time you want to create a document offline, simply press the **Search** key and click on **Google Docs**, **Google Sheets**, or **Google Slides**.

Find other useful offline apps at the Chrome Web Store by pressing the **Search** key and clicking on **Store**. When the Chrome Web Store opens, click on **Collections** in the left column and then **Offline Apps**.

The **Get Started** app and **Help** on your Acer Chromebase have a lot of additional very useful information. They are well worth a look.


Settings

Use the settings menu to adjust the various options for your Acer Chromebase. To access the settings menu:

1. Click on the status area in the lower-right corner, where your account picture appears.
2. Click on **Settings**.



3. To show the advanced settings, scroll to the bottom and click on **Show advanced settings**.



Changing the language settings

1. Click the status area in the lower-right corner, where your account picture appears.
2. Click on **Settings**.
3. Click on **Show advanced settings**.
4. Scroll down and click on **Customize languages and input**.
5. Click on **Add** to add additional languages.

6. To enable a language for keyboard input, select the checkbox next to the language after adding it.
7. Click on **OK** when finished.

Changing the clock settings

You can change the time format and time zone on your Acer Chromebase. If the date or time is incorrect on your Acer Chromebase, try adjusting the time zone.

To change the time zone:

1. Click the status area in the lower-right corner, where your account picture appears.
2. Click on **Settings**.
3. Click on **Show advanced settings**.
4. Scroll down and click on the drop down box next to **Time zone**.

Customizing appearance

Customizing the wallpaper

1. Click the status area in the lower-right corner, where your account picture appears.
2. Click on **Settings**.
3. Click on **Set wallpaper**.
4. Select a preloaded wallpaper or click **Browse** to select your own image. You can also choose **I'm feeling lucky** to have the wallpaper change randomly.
5. Once selected, click **OK**.

Customizing the theme

1. Click the status area in the lower-right corner, where your account picture appears.
2. Click on **Settings**.
3. Click on **Get themes**.
4. You'll be taken to the Chrome Web Store, where you can find extra resources for the Chrome browser.
5. Once you find a theme that you'd like to try out, click **Choose theme**.


Setting up a printer

You can use the Google Cloud Print service to send print requests to your printer. Not all printers are supported.

To learn more about Google Cloud Print and how to set up your printer, connect to the Internet to access the more extensive online help from **"Online and offline help" on page 26** and then search for **Google Cloud Print**.

Updating Chrome OS

Automatic update

Each time you turn on your Acer Chromebase, it automatically checks for updates. When an update is available, this update icon () will appear in the status area. To apply the update:

1. Click the status area in the lower-right corner, where your account picture appears.
2. Click **Restart to update**.
3. Your Acer Chromebase will shutdown and automatically restart, with the update applied.

Manual update

To manually check for an update or check what version of Chrome OS you are using:

1. Click the status area in the lower-right corner, where your account picture appears.
2. Click on **Settings**.
3. In the new tab that opens, click on **Help** in the left column.
4. If any updates are available, they will be displayed on the page.




.....

Warning! Do not modify your Acer Chromebase's hardware yourself. Doing so will cause the update function to no longer work. Please get in touch with your dealer or an authorized service center. Visit www.acer.com to find an authorized service site.

Help

Online and offline help

Additional help is available both online and offline. Help covers basic troubleshooting as well as more detailed information about Chrome OS and using your Chromebase.



To access the help pages:

1. Click the status area in the lower-right corner where your account picture appears.
2. Click on the question mark <?>.



Note: If you are connected to the Internet, the more extensive online help will automatically open. Otherwise, the offline help will open.

Information for your safety and comfort

Safety instructions

Read these instructions carefully. Keep this document for future reference. Follow all warnings and instructions marked on the product.

Turning the product off before cleaning

Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.

CAUTION for plug as disconnecting device

Observe the following guidelines when connecting and disconnecting power to the power supply unit:

Install the power supply unit before connecting the power cord to the AC power outlet.

Unplug the power cord before removing the power supply unit from the computer.

If the system has multiple sources of power, disconnect power from the system by unplugging all power cords from the power supplies.

CAUTION for Accessibility

Be sure that the power outlet you plug the power cord into is easily accessible and located as close to the equipment operator as possible. When you need to disconnect power to the equipment, be sure to unplug the power cord from the electrical outlet.

CAUTION for bundled dummy cards (only for certain models)

Your computer shipped with plastic dummies installed in the card slots. Dummies protect unused slots from dust, metal objects or other particles. Save the dummies for use when no cards are in the slots.

Warnings

- Do not use this product near water.
- Do not place this product on an unstable cart, stand or table. If the

product falls, it could be seriously damaged.

- Slots and openings are provided for ventilation to ensure reliable operation of the product and to protect it from overheating. These openings must not be blocked or covered. The openings should never be blocked by placing the product on a bed, sofa, rug or other similar surface. This product should never be placed near or over a radiator or heat register, or in a built-in installation unless proper ventilation is provided.
- Never push objects of any kind into this product through cabinet slots as they may touch dangerous voltage points or short-out parts that could result in a fire or electric shock. Never spill liquid of any kind onto or into the product.
- To avoid damage of internal components and to prevent battery leakage, do not place the product on a vibrating surface.
- Never use it under sporting, exercising, or any vibrating environment which will probably cause unexpected short current or damage rotor devices, hard disk drive, optical drive, and even exposure risk from lithium battery pack.
- The bottom surface, areas around ventilation openings and AC adapter may get hot. To avoid injury, ensure they do not come in contact with your skin or body.



Note: Reduce the risk of heat-induced injury or fire by adhering to the following:

- 1) Do not place the computer or AC adapter on a soft surface, such as a bed.
- 2) Do not rest the computer or AC adapter on your lap for extended periods.
- 3) Use the computer on a flat, hard surface, such as a desk.
- 4) Ensure that the ventilation is not obstructed.

- Your device and its enhancements may contain small parts. Keep them out of the reach of children.
- The surface temperature of the base will rise during normal operation, particularly when AC power is present. Allowing sustained contact with exposed skin can cause discomfort.

Using electrical power

- This product should be operated from the type of power indicated on the marking label. If you are not sure of the type of power available, consult your dealer or local power company.
- Do not allow anything to rest on the power cord. Do not locate this

product where people will walk on the cord.

- If an extension cord is used with this product, make sure that the total ampere rating of the equipment plugged into the extension cord does not exceed the extension cord ampere rating. Also, make sure that the total rating of all products plugged into the wall outlet does not exceed the fuse rating.
- Do not overload a power outlet, strip or receptacle by plugging in too many devices. The overall system load must not exceed 80% of the branch circuit rating. If power strips are used, the load should not exceed 80% of the power strip's input rating.
- This product's AC adapter is equipped with a three-wire grounded plug. The plug only fits in a grounded power outlet. Make sure the power outlet is properly grounded before inserting the AC adapter plug. Do not insert the plug into a non-grounded power outlet. Contact your electrician for details.



.....

Warning! The grounding pin is a safety feature. Using a power outlet that is not properly grounded may result in electric shock and/or injury.



.....

Note: The grounding pin also provides good protection from unexpected noise produced by other nearby electrical devices that may interfere with the performance of this product.

- The system can be powered using a wide range of voltages: 100 to 120 or 220 to 240 V AC. The power cord included with the system meets the requirements for use in the country/region where the system was purchased. Power cords for use in other countries/regions must meet the requirements for that country/region. For more information on power cord requirements, contact an authorized reseller or service provider.

Product servicing

Do not attempt to service this product yourself, as opening or removing covers may expose you to dangerous voltage points or other risks. Refer all servicing to qualified service personnel.

Unplug this product from the wall outlet and refer servicing to qualified service personnel when:

- The power cord or plug is damaged, cut or frayed.

- Liquid was spilled into the product.
- The product was exposed to rain or water.
- The product has been dropped or the case has been damaged.
- The product exhibits a distinct change in performance, indicating a need for service.
- The product does not operate normally after following the operating instructions.



.....

Note: Adjust only those controls that are covered by the operating instructions, since improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to normal condition.

Radio frequency interference



.....

Warning! For safety reasons, turn off all wireless or radio transmitting devices when using your laptop under the following conditions. These devices may include, but are not limited to: wireless LAN (WLAN), Bluetooth and/or 3G.

Remember to follow any special regulations in force in any area, and always switch off your device when its use is prohibited or when it may cause interference or danger. Use the device only in its normal operating positions. This device meets RF (Radio Frequency) exposure guidelines when used normally. It should not contain metal and you should position the device the above-stated distance from your body. To successfully transmit data files or messages, this device requires a good quality connection to the network. In some cases, transmission of data files or messages may be delayed until such a connection is available. Ensure that the above separation distance instructions are followed until the transmission is completed. Parts of the device are magnetic. Metallic materials may be attracted to the device, and persons with hearing aids should not hold the device to the ear with the hearing aid. Do not place credit cards or other magnetic storage media near the device, because information stored on them may be erased.

Medical devices

Operation of any radio transmitting equipment, including wireless phones, may interfere with the functionality of inadequately protected medical devices. Consult a physician or the manufacturer of the medical device to

determine if they are adequately shielded from external RF energy or if you have any questions. Switch off your device in health care facilities when any regulations posted in these areas instruct you to do so. Hospitals or health care facilities may be using equipment that could be sensitive to external RF transmissions.

Pacemakers. Pacemaker manufacturers recommend that a minimum separation of 15.3 centimeters (6 inches) be maintained between wireless devices and a pacemaker to avoid potential interference with the pacemaker. These recommendations are consistent with the independent research by and recommendations of Wireless Technology Research. Persons with pacemakers should do the following:

- Always keep the device more than 15.3 centimeters (6 inches) from the pacemaker
- Not carry the device near your pacemaker when the device is switched on.

If you suspect interference, switch off your device, and move it.

Hearing aids. Some digital wireless devices may interfere with some hearing aids. If interference occurs, consult your service provider.

Vehicles

RF signals may affect improperly installed or inadequately shielded electronic systems in motor vehicles such as electronic fuel injection systems, electronic anti-skid (anti-lock) braking systems, electronic speed control systems, and air bag systems. For more information, check with the manufacturer, or its representative, of your vehicle or any equipment that has been added. Only qualified personnel should service the device, or install the device in a vehicle. Faulty installation or service may be dangerous and may invalidate any warranty that may apply to the device. Check regularly that all wireless equipment in your vehicle is mounted and operating properly. Do not store or carry flammable liquids, gases, or explosive materials in the same compartment as the device, its parts, or enhancements. For vehicles equipped with an air bag, remember that air bags inflate with great force. Do not place objects, including installed or portable wireless equipment in the area over the air bag or in the air bag deployment area. If in-vehicle wireless equipment is improperly installed, and the air bag inflates, serious injury could result. Using your device while flying in aircraft is prohibited. Switch off your device before boarding an aircraft. The use of wireless teledevices in an aircraft may be dangerous to the operation of the aircraft, disrupt the wireless telephone network, and may be illegal.

Potentially explosive environments

Switch off your device when in any area with a potentially explosive atmosphere and obey all signs and instructions. Potentially explosive atmospheres include areas where you would normally be advised to turn off your vehicle engine. Sparks in such areas could cause an explosion or fire resulting in bodily injury or even death. Switch off the device at refueling points such as near gas pumps at service stations. Observe restrictions on the use of radio equipment in fuel depots, storage, and distribution areas; chemical plants; or where blasting operations are in progress. Areas with a potentially explosive atmosphere are often, but not always, clearly marked. They include below deck on boats, chemical transfer or storage facilities, vehicles using liquefied petroleum gas (such as propane or butane), and areas where the air contains chemicals or particles such as grain, dust or metal powders. Do not switch the notebook on when wireless phone use is prohibited or when it may cause interference or danger.

Emergency calls

Warning: You cannot make emergency calls through this device. To make an emergency call you shall dial out through your mobile phone or other telephone call system.

Disposal instructions

Do not throw this electronic device into the trash when discarding.

To minimize pollution and ensure utmost protection of the global environment, please recycle. For more information on the Waste from Electrical and Electronics Equipment (WEEE) regulations, visit www.acer-group.com/public/Sustainability/sustainability01.htm.



ENERGY STAR



Acer's ENERGY STAR qualified products save your money by reducing energy cost and protecting the environment without sacrificing features or performance. Acer is proud to offer our customers products with the ENERGY STAR mark.

What is ENERGY STAR?

Products that are ENERGY STAR qualified use less energy and prevent greenhouse gas emissions by meeting strict energy efficiency guidelines set by the U.S. Environmental Protection Agency. Acer is committed to

offering products and services worldwide that help customers save money, conserve energy and improve the quality of our environment. The more energy we can save through higher energy efficiency, the more we reduce greenhouse gases and the risks of climate change. More information refers to

www.energystar.gov or www.energystar.gov/powermanagement.

Acer ENERGY STAR qualified products: (only for certain models)

- Produce less heat and reduce cooling loads, and warmer climates.
- Automatically go into "display sleep" and "computer sleep" mode after 10 and 30 minutes of inactivity respectively.
- Wake the computer from sleep mode by pushing keyboard or moving mouse.
- Computers will save more than 80% energy at "sleep" mode.

ENERGY STAR is only available for certain models and have the ENERGY STAR certification mark on the palm rest.

ENERGY STAR and the ENERGY STAR mark are registered U.S. marks

Tips and information for comfortable use

Computer users may complain of eyestrain and headaches after prolonged use. Users are also at risk of physical injury after long hours of working in front of a computer. Long work periods, bad posture, poor work habits, stress, inadequate working conditions, personal health and other factors greatly increase the risk of physical injury.

Incorrect computer usage may lead to carpal tunnel syndrome, tendonitis, tenosynovitis or other musculoskeletal disorders. The following symptoms may appear in the hands, wrists, arms, shoulders, neck or back:

- Numbness, or a burning or tingling sensation.
- Aching, soreness or tenderness.
- Pain, swelling or throbbing.
- Stiffness or tightness.
- Coldness or weakness.

If you have these symptoms, or any other recurring or persistent discomfort and/or pain related to computer use, consult a physician immediately and inform your company's health and safety department.

The following section provides tips for more comfortable computer use.

Finding your comfort zone

Find your comfort zone by adjusting the viewing angle of the monitor, using a footrest, or raising your sitting height to achieve maximum comfort.

Observe the following tips:

- Refrain from staying too long in one fixed posture.
- Avoid slouching forward and/or leaning backward.
- Stand up and walk around regularly to remove the strain on your leg muscles.
- Take short rests to relax your neck and shoulders.
- Avoid tensing your muscles or shrugging your shoulders.
- Install the external display, keyboard and mouse properly and within comfortable reach.
- If you view your monitor more than your documents, place the display at the center of your desk to minimize neck strain.

Taking care of your vision

Long viewing hours, wearing incorrect glasses or contact lenses, glare, excessive room lighting, poorly focused screens, very small typefaces and low-contrast displays could stress your eyes. The following sections provide suggestions on how to reduce eyestrain.

Eyes

- Rest your eyes frequently.
- Give your eyes regular breaks by looking away from the monitor and focusing on a distant point.
- Blink frequently to keep your eyes from drying out.

Display

- Keep your display clean.
- Keep your head at a higher level than the top edge of the display so your eyes point downward when looking at the middle of the display.
- Adjust the display brightness and/or contrast to a comfortable level for enhanced text readability and graphics clarity.
- Eliminate glare and reflections by:
 - placing your display in such a way that the side faces the window or any light source
 - minimizing room light by using drapes, shades or blinds
 - using a task light
 - changing the display's viewing angle
 - using a glare-reduction filter

- using a display visor, such as a piece of cardboard extended from the display's top front edge
- Avoid adjusting your display to an awkward viewing angle.
- Avoid looking at bright light sources for extended periods of time.

Developing good work habits

The following work habits make computer use more relaxing and productive:

- Take short breaks regularly and often.
- Perform some stretching exercises.
- Breathe fresh air as often as possible.
- Exercise regularly and maintain a healthy body.



.....
Warning! We do not recommend using the computer on a couch or bed. If this is unavoidable, work for only short periods, take breaks regularly, and do some stretching exercises.

Regulations and safety notices

FCC notice

This device has been tested and found to comply with the limits for a Class B digital device pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the device and receiver.
- Connect the device into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/television technician for help.

Notice: Shielded cables

All connections to other computing devices must be made using shielded cables to maintain compliance with FCC regulations.

Notice: Peripheral devices

Only peripherals (input/output devices, terminals, printers, etc.) certified to comply with the Class B limits may be attached to this equipment. Operation with non-certified peripherals is likely to result in interference to radio and TV reception.

Caution

Changes or modifications not expressly approved by the manufacturer could void the user's authority, which is granted by the Federal Communications Commission, to operate this computer.

Operation conditions

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Notice: Canadian users

This Class B digital apparatus complies with Canadian ICES-003.

Remarque à l'intention des utilisateurs canadiens

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

LCD pixel statement

The LCD unit is produced with high-precision manufacturing techniques. Nevertheless, some pixels may occasionally misfire or appear as black or red dots. This has no effect on the recorded image and does not constitute a malfunction.



Acer America Corporation
333 West San Carlos St., Suite 1500
San Jose, CA 95110, U. S. A.
Tel : 254-298-4000
Fax : 254-298-4147
www.acer.com



Federal Communications Commission Declaration of Conformity

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The following local Manufacturer /Importer is responsible for this declaration:

Product:	Chrome All-in-One
Model Number:	DC221HQ
SKU Number:	DC221HQ xxxxxx ("x" = 0~9, a~z, or A~Z)
Name of Responsible Party:	Acer America Corporation
Address of Responsible Party:	333 West San Carlos St. Suite 1500 San Jose, CA 95110 U. S. A.
Contact Person:	Acer Representative
Phone No.:	254-298-4000
Fax No.:	254-298-4147