


In [Windows Mode]

- 1.1 Get Acer BIOS Package.
- 1.2 Copy "UCP" folders including files to a storage device.


[By Windows command line](#)

2. Run execution file as **Administrator** in Windows.


<Windows 10>



2.1 Choose "YES" to execute.



2.2 The system will ask System is going to shut down, are you ready?



2.3 Press<Y>, system will be going to shut down.



2.4 System will auto reboot and flash BIOS.

